

## Hangar Power Distribution



Fuse-Switch protected Earth Leakage/Earth Monitoring cluster assemblies for portable applications to protect Ground Support Equipment.

Specifications available to suit individual requirements.

Compliant with Technical Bulletin  
TB03/05

## Typical Assembly

1X125A TP Fuse-switch

1X 125A TP&N Earth Leakage/Earth Monitoring Protected Skt


2X 32A TP Fuse-switch

2X 32A TP&N Earth Leakage/Earth Monitoring Protected Skt

Order Ref: HPD3/125/2X32

## Typical Schematic Installation

This installation utilises FDB 7 Earth Monitoring Skts at the supply point to ensure Earth Monitoring to the HPD unit which then supplies Earth Leakage & Earth Monitoring protection to the equipment.



FDB Electrical Ltd

Unit 20 Worton Hall Industrial Estate

Worton Road

Isleworth

Middlesex

TW7 6ER

Tel: 0208 5684621

Fax: 0208 5697899